To Connect Top Crescent to Bottom Crescent for Taller C Frame:

Insert Small Connecting Pipe in to bottom Crescent. Attach 2 smaller bolts on each side.
Connect Top Crescent and insert 2 smaller bolts on each side.

All other Instructions are the same.

Thank You again!

Ez Hang Chairs