EZ Hang Loveseat Spreader Bar instructions

Your EZ Hang Love Seat comes with hanging hardware and chain suitable for most standard porch swing frames, such as our own Roman Arch wooden frame (pictured at left). You may, however, choose to hang yours from a tree limb, porch overhang, or other suitable structure. You can purchase chain in the proper length and gauge at any hardware store. Make sure you observe our own 500 lb rating when selecting additional chain and/or hardware, and that you mount your loveseat into a structure capable of handling that weight.

When hanging your Love Seat from a hang point taller than 66” (5 1/2’), the footrests might not hang conveniently from the same place as the Love Seat. For this reason, we have included a 51” wooden spreader bar and 4 mini eyelag bolts in order to provide a handy hang point for the footrests and/or the optional rain cover.

Insert two of the eyelags into the outermost holes of the spreader bar with the eyes up. Insert the remaining two eyelags into the two centermost holes, eyes down. Secure the eyelags with the washer next to the nut, and tighten all nuts securely. Insert two S-hooks into the outer, up-hanging eyes, and hang the spreader bar 10”-12” above the O-rings tied to each side of the supporting ropes on the Love Seat. Tie or hang the footrests to the inner, down-hanging eyes as shown.

IMPORTANT:
The supplied mini-eyelags and spreader bar are NOT designed to bear the weight of the Love Seat itself, and should NOT in any way be inserted into the weight bearing system. Do NOT hang the any supporting rope, chain, or the Love Seat off of the mini eyelags or spreader bar.