If you have any questions regarding our products please
call our toll-free customer service line :877-242-4775
or visit our website: www.ezhangchairs.com

Assembly instructions for EZ Frame

Parts Included:

(1) X Section of Frame

(2) Lower Section of Frame

(3) Top Section of frame

(4) 2 additional side support brackets

(5) Hardware Pack, Tool, Instructions



Assembly Instructions

(6) Insert lower section of frame into the center hole of X section. Connect the two sections using the long bolt in the top hole and short bolt in bottom hole. The top long bolt goes all the way through when completely tightened. Tilting the frame forward can assist in correctly aligning bolts.

(7) Connect top section to the lower section and align holes and tighten completely with the two allen bolts.

(8) If desired attach two side support brackets to the X section of the frame using the hardware included.

(9) Hang chair from Hook point at top of upper section.





Care – It may be necessary to spray frame occasionally with rust preventative spray paint to enhance appearance.

Reminder – The frame is not intended to swing or twist in. Always exit frame front to back and not sideways. Use caution.

Disclaimer

EZ Hang Chairs and all agents thereof cannot assume responsibility for special, indirect, or consequential damages,injury,or contingent liability for use of this product in a manner not intended by manufacturer. End consumer is ultimately responsible for verifying proper assembly of frame.